



Register code

000 B	001 C	010 D	011 E
100 H	101 L	110 M	111 A



Pair code

00 B	01 D	10 H	11 SP
------	------	------	-------



'MOV E,H': 01 011 100 = 5C₁₆ 'MVI D': 00 010 110 = 16₁₆